

THERMOREFLEX® PLUS

SPECIFICATIONS

Composition	± ↑ Average Thickness	Carrier	♣ Certifications			
PU	170 microns	Non adhesive polyester	REACH n° 1907/2006/EU EN 20471 OEKO-TEX ® CONFIDENCE IN TEXTILES STANDARD 100 19.HIT.86736 HOHENSTEIN HTTI			

APPLICATION INSTRUCTIONS

	SUGGESTED CUTTING SETTINGS			TRANSFER SETTINGS			
cotton, polyester, poly/cotton blends (not suited for treated and dye sublimated textiles)	Blade	<u></u> Pressure	>> Speed	Time	Temperature	Pressure	Peel
	45°	from 70 to 100 with new blade, 110 with used blade	20cm/sec	5+10 seconds	155°C (311°F)	Medium (2,5/ 3,5 bar)	warm

- → Mirror cut the design
- → Weed excess material
- → Place the design on the garment
- → Transfer for 5" under suggested conditions
- → Remove the carrier in warm conditions
- → Cover with baking paper
- → Press another 10" for final fixing

PRODUCT HIGHLIGHTS

- → High retroreflectivity power
- → Follows EN ISO 20471 regulation
 - $oldsymbol{arGamma}$ NOTE: We highly recommend to perform a test before launching a production

CARE AND WASHING RECOMMENDATIONS

W ashing	Ironing	Tumble dry	Ony cleaning	Storage Shelf Life	Storage Temperature	Storage Conditions	∮ Position
Up to 60°C, best inside-ou	YES t best inside-out	YES (cotton cycle)	NO	Up to 2 years	Between 18°C and 26°C	Away from sunlight and dust	Vertical

- → Wait 24 hours after the application before the first wash
- → Respect the textile recommendations
- → Do not bleach or use aggressive chemical agents

